

3350 Davie Road, Suite 203 Davie, FL 33314 (954)463-1075

www.kus-usa.com www.kusauto.com/en

## **Product Data Sheet**








Description:	The NMEA tachometer gauge allows the user to remotely monitor to monitor the gear speed of their engine. These tachometer gauges will work with NMEA 2000 senders or resistive type senders with an analog converter.
Product Type:	Water Tachometer Gauge
Product Name:	NMHB
Bezel:	SUS 316 Stainless Steel
Face Plate:	Black White
<b>Mounting Dimension:</b>	85mm, 3 3/8"
Protection Rating:	IP 67
Input Signal:	NMEA 2000 & J1939
Indicating Range:	0 - 7000RPM
Operating Voltage:	12V/24V
Background light	Red LED
Connector:	Standard NMEA 2000 cable. 1 meter long
Movement:	Cross coil motor movement



3350 Davie Road, Suite 203 Davie, FL 33314 (954)463-1075

www.kus-usa.com www.kusauto.com/en

## **Installation Instructions**



## **INSTALLATION STEPS**

- 1. Cut a 85 mm(3 3/8") diameter panel hole(# II). You will need a minimum clearance of 85 mm(3 3/8") behind the panel to fit the gauge(# III).
- 2. Place the gauge body (# III) in the panel hole(# II), and then fasten it with fastening ring(# I).
- 3. Insert wire harness into port, and connect the ventilation hose with the bronze fitting of speedometer. Please make sure the connection is tight.
- 4. According to wiring instruction to do wire connection. Gauge can be connected to 12VDC and 24VDC power directly.
- 5. Select either red or yellow backlight by your fondness.